350VL Ambulatory Pumps Patient Quick Reference Card

Precision • Quality • Performance

Keep this card in your carrying pouch or on your person. For complete guidance, refer to the instructions given to you by your health care provider.

Brief Instructions

To Start Medication Delivery:

- Press the POWER key to turn pump on. The pump will display key to turn pump on. The
- Press the START ▶ key to begin delivery.
 The ➡➡ light will start blinking green. The display will alternate between delivery rate and volume delivered screens.
- 3. Place front cover on pump.

To Stop Medication Delivery:

1. Press the STOP 🔀 key. The pump will display 🛛 ք

To Change the Battery:

Use a 9-volt alkaline battery. Duracell® MN 1604 recommended.

- 1. Press the STOP <mark>ඎ key</mark> and turn pump off **◎**.
- Remove battery. Wait approximately 15 seconds before installing new battery.

3.	Follow	Start	Medication	Delivery	instructions	above.

Additional Information:									

w 1

WalkMed, LLC

14190 E. Jewell Ave, Unit 10 Aurora, CO 80012, USA 303-420-9569, 800-578-0555



Problem Solving Table

Software Revision Level 2.0 [.1-.9]

- Match the message you see on your pump display with the Display Message in the left column below.
- 2. Follow the Corrective Action given in the right column.
- If you cannot correct the problem following the Corrective Action, follow the directions given by your health care provider.

Display Sounds/ Condition **Corrective Action** Lights Message Sounds: Not Press key to start IdLE Slow beeping delivering delivery. Or Press 🔀 key to silence alert for 5 minutes. Light: - III 888 Blinking yellow Press key to start Sounds: I ow Slow beeping battery delivery. Replace battery within 30 Light: minutes Blinking yellow Sounds: Depleted Remove depleted dEP battery to silence alarm. Continuous batterv tone Replace battery. Press (b) key to turn pump Light: - 🔼 Continuous red Press key to restart. Sounds: Clamp bar Press key to silence d.DP Continuous is open alert tone Close clamp bar. Press key to restart. Light: Blinking red Sounds: IV tubina Check tubing system for 000 Continuous occlusion kinks and correct. tone Pump will resume delivery when line is cleared. Light: -Press 5 key to silence Blinking red alert. Check tubing system for kinks and correct. Press key to restart. Sounds: System Write down Error Er.. Continuous malfunction message from display. tone Remove battery to silence 1-8, alarm. Light: -Take pump out of service. O or U will Continuous red appear Contact support with Error here message. scrolling The pump will continue delivery at the KVO rate for approximately 4 hours Sounds: Total Slow beeping volume End limit 0.50 Light: 💳 🕮 reached An audible alert will beep Blinking yellow every 30 minutes. 10.5 Fnd of KVO Sounds: Press key to silence alert. End Fast beeping Clear END alert by: Reset volume delivered. - or - Increase total Light: — 🕮 volume limit amount. Blinking red - or - Set total volume limit to OFF Failed key Press (b) key to turn pump 18.8.8 in keypad off. Take pump out of service. Remove battery and wait 15 seconds before Sounds: System Continuous malfunction re-installing tone during battery Light: install

Continuous red